



Computer Vision

Robotics and Vision

27 August 2008

Copyright © 2001 – 2007 by
Noordelijke Hogeschool Leeuwarden and Van de Loosdrecht Machine Vision
Thomas Osinga
All rights reserved

j.van.de.loosdrecht@tech.nhl.nl, jaap@vdlmv.nl

Overview robotics and vision

- Introduction to Robots
- Introduction to Robotics
- VisionAria
- Overview of Visionlab and VisionAria
- VisionAria Commands
- Connecting the robot
- General commands
- Moving the robot
- Sonar system
- Arm general commands
- Arm moving
- RoboChallenge

28-8-2008

Computer Vision

2

Introduction to Robots

The word robot is used to refer to a wide range of machines, the common feature of which is that they are all capable of movement and can be used to perform physical tasks.

Definition of Robot:

“An automatically controlled, reprogrammable, multipurpose, manipulator, which may be either fixed in place or mobile for use in automation applications.”

Definition of Robotics:

“Robotics is the science and technology of robots, their design, manufacture, and application.”



28-8-2008

Computer Vision

3

Mobile Robotics



The robots used in this course are from Mobile Robots.

All robots use Arcos as their embedded software (Firmware)


With the Mobile Robots ‘Advanced Robot Interface for Applications’ (ARIA) you are able to dynamically control every robot which uses Arcos.



28-8-2008

Computer Vision



4



Things to take in account

When you are working on the robot you have to take a few precautions.

- Place the robot on the holder when the robot is on a desk.
- After working with the robot connect him to the charger.
- Always use a slow speed for the robot and pioneer arm.
- Standby, hit the emergency button when needed.
- Be careful with this expensive equipment.

28-8-2008 Computer Vision 6

VisionAria

VisionAria is a library to extend the functionality of Visionlab with commands to use a Aria based robot.

53 Aria Commands
For controlling a Aria Based Robot


28 ArAkin Arm Commands
For controlling a ArAkin Based Arm

28-8-2008

Computer Vision

7

Overview of Visionlab and VisionAria




28-8-2008

Computer Vision

8

VisionAria Commands

All VisionAria commands can be found under Aria and Aria Arm.



28-8-2008


Computer Vision

9

Connecting the robot

To communicate between the robot and VisionAria you need to connect them. The connection can be established with a serial RS232 connector.

- Connect the robot with the computer
- Turn the Robot on



Now you are ready to use the robot

28-8-2008

Computer Vision

10

Controlling the robot

Now it's time to control the robot. The most important VisionAria commands will be explained. Controlling the robot is divided in the following parts.

- General commands
- Moving the robot
- Sonar system
- Arm general commands
- Arm moving

28-8-2008

Computer Vision

11

General Commands

First things first. We start with some basic robot commands.

- **aria_init** (*Initializes the robot*)
- **aria_shutdown** (*shutdown the robot*)
- **aria_stop** (*stops the robot*)

- **aria_setrobotspeed <speed>** (sets the speed of the robot in mm/sec
800 is fast 400 normal 200 slow)
- **aria_wait** (*wait until the robot stops moving*)
- **aria_sleep <msec>** (waits <msec> after the robot moving)

28-8-2008

Computer Vision

12

Moving the Robot

Now we now the general commands we can start with letting the robot move. The robot can either move (forward or backward) or rotate (clockwise or counter clockwise).

- **aria_move <distance>** (*moves the robot. Distance is in cm. When distance is below zero the robot moves backwards*)
- **aria_rotateleft <degrees>** (*rotate's the robot counter clockwise*)
- **aria_rotateright <degrees>** (*rotate's the robot clockwise*)

28-8-2008

Computer Vision

13

One Small step for man, one Giant roll for a robot

- Create new script
- Insert the next lines in the script

```
aria_init
aria_setrobotspeed 200
aria_move 200
aria_wait
aria_rotateleft 90
aria_wait
aria_shutdown
```

- Execute script



make sure there is enough space for the robot to move.

28-8-2008

Computer Vision

14

One Small step for man, one Giant roll for a robot

The robot will move 20 cm forward and the rotate 90 degrees.
The speed of the robot has been set to 200 so the robot will not move to fast.

Moving shape



28-8-2008

Computer Vision

15

Exercise moving the robot

Create new script which:

- Lets the robot drive a square shape
- The robot has to finish on the same point it started
- Shutdown the robot at the end of the script



Be sure that you don't hit any object!

Moving shape



Answer: move.js

28-8-2008

Computer Vision

16

Moving the Robot Smoothly

The following commands don't wait until the last move is done and are there for easy for making smooth moves.

- **aria_movesmooth <distance>** (*moves the robot. Distance in cm. When distance is below zero the robot moves backwards*)
- **aria_adjustleft <degrees>** (*rotate's the robot counter clockwise*)
- **aria_adjustright <degrees>** (*rotate's the robot clockwise*)

28-8-2008

Computer Vision

17

Moving the Robot Smoothly

- Create new script
- Insert the next lines in the script

```
aria_init  
aria_setrobotspeed 200  
aria_movesmooth 500  
aria_adjustleft 90  
aria_shutdown
```

- Execute script



make sure there is enough space for the robot to move.

28-8-2008


Computer Vision

18

One Small step for man, one Giant roll for a robot

The robot will move 500 cm forward. But because there is a `aria_adjustleft 90` after the move operation the robot will not wait for the move to finish.

Moving shape



28-8-2008

Computer Vision

19

Exercise smoothly moving the robot


Create new script which:

- Sets the speed of the robot to 200
- Lets the robot drive a sinus shape
- Shutdown the robot at the end of the script



Be sure that you don't hit any object!

Moving shape



Answer: movesmooth.js

28-8-2008

Computer Vision

20

Sonar system

The following commands concern the sonar system. Sonar works with sounds which are transmitted. The time it takes to get return to the sonar indicates a distance.

- **aria_addsonar** (Adds the sonar function to the robot. Standard collision detecting is enabled by using this function.)
- **aria_sonarspeed <speed>** (Changes the speed of the sonar. Sets the time it takes to make a full sonar cycle)
- **aria_sonarstopaction** (Action with the sonar. If an object is getting closer to the robot than the <stopdistance> variable, the robot will cancel its movement forward and continue with the next command.)
- **aria_sonarnoaction** (Default action with the sonar. If an object is getting closer to the robot than the <stopdistance> variable, the robot will halt until the object moves away. After that the robot continues his way.)
- **aria_setsonarnear<stopdistance><slowdistance><slowspeed>**
(Changes the parameters for the sonar collision detection in the near surrounding. Standard is: <300> <600> <250>. <stopdistance> is the distance to stop, slowdistance is the distance from where to go at max <slowspeed>.)
- **aria_setsonarback<stopdistance><slowdistance><slowspeed>**(see above)
- **aria_getsonarrange <sonar>** (Gets the sonar reading from a single sonar sensor.)

28-8-2008

Computer Vision

21

Stopping on Sonar

- Create new script
- Insert the next lines in the script

```
aria_init
aria_addsonar
aria_sonarspeed 10
aria_setsonarnear 200 10 400
aria_sonarstopaction
```

```
while true do
  aria_move 200
  aria_wait
endwhile
```

```
aria_shutdown
```

- Execute script



make sure there is enough space for the robot to move.

28-8-2008

Computer Vision

22

Stopping on Sonar

In a while loop the robot is moved 20 cm. When there is an object in the range of 20 cm the robot will stop. When the object is removed the robot will continue.

To act on a sonar you need some more commands.

- **aria_frontsonar_washalted** (returns true when the robot has been halted on a object in front of him.)
- **aria_backsonar_washalted** (returns true when the robot has been halted on a object behind him.)

28-8-2008

Computer Vision

23

Acting on Sonar

- Create new script
- Insert the next lines in the script

```
aria_init
aria_addsonar
aria_sonarspeed 10
aria_setsonarnear 200 10 400
aria_sonarstopaction
while true do
  $halted = aria_frontsonar_washalted
  syncvars
  if $halted === false then
    aria_move 200
    aria_wait
  endif
  if $halted === true then
    aria_remfrontsonar
    aria_rotateright 30
    aria_wait
    aria_addfrontsonar
  endif
endwhile
aria_shutdown
```

Execute script



Make sure there is enough space for the robot to move.

28-8-2008

Computer Vision

24

Acting on sonar

With `aria_frontsonar_washalted` you check if there is an object in front of the robot. If there isn't an object the robot will move 20 cm forward.

```
if $halted === false then
  aria_move 200
  aria_wait
endif
```

If there isn't the sonar is stopped so the robot can rotate. After the rotation the sonar is turned on again.

```
if $halted === true then
  aria_remfrontsonar
  aria_rotateright 30
  aria_wait
  aria_addfrontsonar
endif
```

! When there is an object the `aria_sonarstopaction` will stop the last command. You need to turn off the sonar in order to let him rotate.

28-8-2008

Computer Vision

25

Pioneer Arm general commands

The following general commands concern the Pioneer Arm.

- **aria_arm_init** (Initializes the robot arm, prints out information about all the joints of the arm and then powers on the arm itself.)
- **aria_arm_shutdown** (Disconnect the robot arm from the robot.)
- **aria_arm_wait** (Waits until the arm has stopped moving.)
- **aria_arm_home** (Home the arm back to its base)
- **aria_arm_park** (Sends the arm to its home position and parks it by turning the power off.)
- **aria_arm_setjoints_speed <speed>** (Sets the speed of all joints. This value must be between 1 and 127. The value represents ms. Standard value is 1.)
- **aria_arm_setjoint_speed <joint> <speed>** (Sets the speed of a specified joint. The value must be between 1 – 127. The value represents ms. Standard value is 1.)

28-8-2008

Computer Vision

26

Moving the Pioneer Arm

Now we now the general commands of the pioneer Arm we can start with letting the arm move.

- **aria_arm_setjoint <joint> <value>** (Sets the position of the given joint to the given value, if it falls between the minimum and maximum range of the given joint.)
- **aria_arm_setjoint_degrees <joint> <value>** (Sets the position of the joint to a given degree.)
- **aria_arm_setjoints<joint1><joint2><joint3><joint4><joint5><joint6>**(Set s the position of every joint, if it falls between the minimum and maximum range of the given joints.)
- **aria_arm_setjoints_degrees <joint1> <joint2> <joint3> <joint4> <joint5> <joint6>** (Sets the position of every joint by a angle.)
- **aria_arm_getjoint_min <joint>** (Gets the minimal position of the given joint.)
- **aria_arm_getjoint_max <joint>** (Gets the maximum position of the given joint.)
- **aria_arm_getjoint_center <joint>** (Sets the position of every joint by a angle.)

28-8-2008

Computer Vision

27

Moving the Pioneer Arm

- Create new script
- Insert the next lines in the script

```
aria_init
aria_arm_init

aria_arm_setjoints_speed 50
aria_arm_setjoints_degrees 120 130 120 90 90 90
aria_arm_wait
aria_arm_setjoints_degrees 120 50 50 120 120 50
aria_arm_wait

aria_arm_home

aria_arm_wait
aria_arm_shutdown
aria_shutdown
```

- Execute script



make sure there is enough space for the arm to move.

28-8-2008

Computer Vision

28

Moving the Pioneer Arm

The arm is moving to two divert positions. These positions are set with the `aria_arm_setjoints_degrees` command.

Before the arm is shutdown the `aria_arm_home` command is executed.

28-8-2008

Computer Vision

29

Exercise “A helping hand”

Create new script which:

- Sets the speed of the arm to 50 mm/sec
- Lets the arm pickup a ball
- And drop it on the robot
- Shutdown the robot at the end of the script



Be sure that you don't hit any object with the arm!

Answer: `arm_helping.jls`




28-8-2008

Computer Vision

30

Robochallenge

Robot in action at the Robochallenge.




28-8-2008

Computer Vision

31

Robochallenge



28-8-2008

Computer Vision

32

All Aria commands

aria_init	aria_shutdown	aria_engineenable
aria_enginedisable	aria_reset	aria_wait
aria_sleep<msec>	aria_move <distance>	aria_movesmooth<distance>
aria_setrobotsspeed <speed>	aria_setaccelspeed <speed>	aria_stoparia_rotateleft<degrees>
aria_rotateright <degrees>	aria_adjustleft <degrees>	aria_adjustright<degrees>
aria_addsonararia_remsonar	aria_sonarstopaction	aria_sonarnoaction
aria_comparessonar<sonar1><sonar2>	aria_comparessonarsides	aria_getsonarrange<sona
aria_rembacksonar	aria_addbacksonar	aria_remfrontsonar
aria_addfrontsonar	aria_sonarspeed <speed>	aria_getdebuginfo<param
aria_resetorigin	aria_getrobotpos	aria_getchargestate
aria_getrobottype	aria_getname	aria_getversion
aria_getbatteryvoltage	aria_play <tones>	aria_robotfindangleto<x><y><
aria_robotfinddistanceto<x><y><th>	aria_com <command>	aria_cominteger <command><arg1>
aria_comstring <command><arg1>	aria_com2byte<command><arg1><arg2>	
aria_logstart<filename>	aria_logstoparia_logadd <text>	
aria_robot_finddeltaheadingto<x><y><th>	aria_frontsonar_washalted	aria_backsonar_washalted
aria_pointfindangleto<x1><y1><th1><x2><y2><th2>		
aria_pointfinddistanceto <x1> <y1> <th1> <x2> <y2> <th2>		
aria_setsonarnear<stopdistance><slowdistance><slowspeed>		
aria_setsonarfar<stopdistance><slowdistance><slowspeed>		
aria_setsonarback<stopdistance><slowdistance><slowspeed>		

28-8-2008

Computer Vision

33

All Aria Arm commands (ArAkin)

aria_arm_init	aria_arm_shutdown
aria_arm_isactive	aria_arm_setjoint <joint> <value>
aria_arm_setjoint_speed <joint><speed>	aria_arm_setjoint_degrees <joint><value>
aria_arm_setjoints<joint1><joint2><joint3><joint4><joint5><joint6>	aria_arm_setjoints_speed<speed>
aria_arm_setjoints_degrees<joint1><joint2><joint3><joint4><joint5><joint6>	
aria_arm_getjoint <joint>	aria_arm_getjoint_min <joint>
aria_arm_getjoint_max <joint>	aria_arm_getjoint_center <joint>
aria_arm_getjoint_home <joint>	aria_arm_test
aria_arm_ispowered	aria_arm_iscommunicating
aria_arm_wait	aria_arm_home
aria_arm_park	aria_arm_movearmtoposition <x> <y> <z>
aria_arm_movearmtoposition_joint <x> <y> <z> <jointangle>	aria_arm_poweron
aria_arm_poweroff	aria_arm_closegripper
aria_arm_opengripper	aria_arm_carry
aria_arm_getversion	

28-8-2008

Computer Vision

34