



Computer Vision



VisionLab development environment

27 August 2008

Copyright © 2001 – 2008 by
Noordelijke Hogeschool Leeuwarden and Van de Loosdrecht Machine Vision
All rights reserved

j.van.de.loosdrecht@tech.nhl.nl, jaap@vdlmv.nl

Overview

- **Development environments (general)**
- **VisionLab**
 - **Overview of system**
 - **Image types**
 - **Co-ordinate system**
 - **Dyadic operators**
 - **Displaying of images**
 - **Using camera**
 - **File Drop Cam (*)**
 - **File Cam (*)**
 - **Online help**
 - **Script language**
 - **Speeding up scripts (*)**
 - **Adding own script as operator (*)**
 - **Adding own C++ operators (*)**

Development environments (general)


- **Image acquisition**
 - **Library with standard operators**
 - **Experiment with operators**
 - Interactive
 - Scripts
 - Graphical programming
 - **Add user defined operators**
 - **Stand-alone applications**
- **Survey of 10 image processing packages by NHL and TNO TPD**

8/28/2008

VisionLab

3

Overview of VisionLab



Demo version can be downloaded from www.vdlmv.nl (Windows and Linux)

8/28/2008

VisionLab

4

Overview of VisionLab

- **VisionLib:**
Library of more the 200 operators for image processing, classifying with neural networks and interfaces to cameras, written in ANSI C++.
- **VisionCmd:**
Command interpreter for scripts. The scripts can be used for easy and fast development of applications or prototypes.
- **VisionServer:**
Shell with a network interface around VisionCmd. With VisionServer it is possible to communicate over the internet with a remote VisionCmd.
- **VisionClient:**
Graphical user interface with which it is possible to experiment in a comfortable way with the VisionLib library and to develop and test scripts. An online help is available.
- **VisionLibNet:**
.NET class library around VisionCmd, making it accessible by all .NET languages.
- **VisionLibDLL:**
dll library around VisionCmd, making it accessible other languages. Delphi wrapper is available.

8/28/2008

VisionLab

5



Demonstration VisionLab

- Start-up VisionLab
 - Show console server
 - Explain Server Log window of client
 - Open circles.jl and show server/client communication
 - Demonstrate opening of *.bmp image, is automatically converted to RGB888Image, use dark_flower.bmp in images directory
-
- Source image circles.jl: Lex van de Voort van de Kleij (NHL)

8/28/2008

VisionLab

6







Image types


- *Image*
 - *NumImage<Pixel>:*
 - *OrdImage<Pixel>:*
 - *IntImage<Pixel>:*
 - *ByteImage*
 - *Int8Image*
 - *Int16Image*
 - *Int32Image*
 - *RealImage<Pixel>:*
 - *FloatImage*
 - *DoubleImage*
 - *ColorImage<Pixel>:*
 - *RGB888Image, RGB161616Image*
 - *HSV888Image, HSV161616Image*
 - *YUV888Image, YUV161616Image*
 - *ComplexImage<Pixel>:*
 - *ComplexFloatImage*
 - *ComplexDoubleImage*

8/28/2008

VisionLab

11

Conversion between Image Types



8/28/2008

VisionLab

12

Co-ordinate system and Dyadic operators

Co-ordinate system

- **Origin: top left corner**
- **X values increase from left to right**
- **Y values increase from top to bottom**

Dyadic operators:

- **Use select second**

8/28/2008

VisionLab

13



Demonstration co-ordinate system and DisplayLUTs

- Show co-ordinate system with Edit
- Demonstrate select second :
 - DisplayLUT for Int16Image = Stretch
 - Copy circles
 - Add the two images
 - No visible difference!
- Show pixel values of both images with Edit
- Explanation in slide about DisplayLUTs

8/28/2008

VisionLab

14



Displaying of images

Server:

- List of images on which operations act

GUI client:

- Display image with use of LookUp Table (LUT)

8/28/2008

VisionLab

17



Demonstration of displaying of images

- Show list of images on server
- Client is 'stupid', it knows nothing about vision operators
- Client can only translate commands and display images
- All vision intelligence is in the server
- Demonstrate applying different LUT's on image, see next slide


8/28/2008

VisionLab

18



See result of adding the two images



8/28/2008

VisionLab

21

Displaying of images



DisplayLUT's (LUT = LookUpTable):


- **IntImage**
 - Stretch
 - Clip
 - Labelled
 - Binary
- **FloatImage**
 - Linear
 - Logarithmic
- **ColorImage**
 - in colour depending on screen settings
- **ComplexImage**
 - power spectrum displayed as **FloatImage**

8/28/2008

VisionLab

22






8/28/2008

VisionLab



25



8/28/2008

VisionLab

26



File Drop Camera (*)

Used as a rudimentary interface to cameras who are able to write bmp or jpg images to file with a file name and a sequence number.

The file name consists of a <File base name> + <sequence nr> + . + <File extension>. The sequence nr is padded with leading 0's if <nr of digits> is greater than 0.

After pressing the start button the image with the specified filename is searched for. If the specified file is not found, processing is postponed until the specified file is created.

If the file is found or created:

- the image is opened and displayed
- the image is selected as script image (%current image)
- the script with <Script name> is executed with the specified <Parameters> the function result of the script is assigned to the specified <Result> variable
- <Sequence nr> is incremented
- the search or wait for the next image starts

8/28/2008

VisionLab

29



Demonstration File Drop Camera (*)

- Move file filedropcam2.bmp from directory to the desktop, leave filedropcam1.bmp in current directory
- Open File Drop Cam form in Camera menu
- Specify the parameters as in the next slide
- Press start button
- File filedropcam1.bmp is in current directory, so the image is opened and selected as %currentimage and script filedropscript.jls is executed
- Because file filedropcam2.bmp is in not in the specified directory, processing is postponed.
- Drop file filedropcam2.bmp back in specified directory, processing continues, image is opened and script is executed


8/28/2008

VisionLab

30



Wait for drop file filedropcam2.bmp back in specified directory (*)




8/28/2008

VisionLab

33

File dropcam2.bmp is processed (*)



8/28/2008

VisionLab

34

FileCam (*)

FileCam is used to 'snapshot' images from a file from disk.

The init string should be used to specify in which mode the camera is operated. Syntax:

<imageType > <fileName>

The file is in normal text file with on each line the file name of an image. It is advised to use a fully specified file names including the full directory path.

Snapshotting will start from the first image in the file.

If more snapshots are taken then images specified in the file, snapshotting will start again from the first image


Use the command LastFileCamName to retrieve the fileName of the last snapshot image.

8/28/2008

VisionLab

35



Example: using a FileCam (*)



8/28/2008

VisionLab

36



Online help

Online help is available:

- **F1**
- **Main menu**

8/28/2008

VisionLab

39



Demonstration online help

- **Search for Threshold operator**
 - **Open image circles.jl**
 - **Select threshold operator and press F1 for online help**
 - **description operator and position in operator menu structure**
 - **Select help from main menu**
 - **Select Find in VisionLab help file window and type threshold**
 - **C++ header file in System Development Kit**


8/28/2008

VisionLab

40



Select help from main menu




8/28/2008

VisionLab

43

Select Find in VisionLab help file window




8/28/2008

VisionLab

44

Help for Threshold (SDK) (*)



```

ordoper.h
/* File : ordoper.h
 * Project : visionlib v3.0
 * Author : Jaap van de Loosdrecht
 *           Van de Loosdrecht Machine Vision
 *           www.vdlmv.nl
 * Date : 2-1-2002
 *
 * Copyright (c) 1993-2002. Van de Loosdrecht Machine Vision.
 * all rights reserved.
 */
#ifndef JL_VIS_LIB_ORDINAL_OPERATORS
#define JL_VIS_LIB_ORDINAL_OPERATORS

#include "numoper.h"
#include "ordimage.h"
#include "rgb888ima.h"
#include <set>

namespace JL_VisionLib_V3 {

enum ObjectBrightness {DarkObject, BrightObject};

template <class OrdImageT, class PixelT>
PixelT AveragePixel (const OrdImageT &image);


template <class OrdImageT, class PixelT>
void ClipPixelValue (OrdImageT &image, const PixelT low, const PixelT high);

template <class OrdImageT, class PixelT>

```

8/28/2008 VisionLab 45

Help for Threshold (SDK) (*)



```

Threshold (OrdImageT &image, const PixelT low, const PixelT high);

ThresholdLocal (OrdImageT &image, const OrdImageT &mask,
                 const ObjectBrightness object);

ThresholdOnHighest (OrdImageT &image);

ThresholdOnLowest (OrdImageT &image);

ThresholdOnLowestButZero (OrdImageT &image);

ThresholdRATS (OrdImageT &image, const PixelT minEdge,
                  const ObjectBrightness object, PixelT &thres);

ThresholdRATS (OrdImageT &image, const OrdImageT &roi,
                  const PixelT minEdge, const ObjectBrightness object,
                  PixelT &thres);

ThresholdRATSLocal (OrdImageT &image, const PixelT minEdge,
                     const double minAvgEdges, const int nrLevels,
                     const ObjectBrightness object);

```

8/28/2008 VisionLab 46

Script language

Scripts can contain different kind of commands:

- **image operators**
- **variables and expressions (*)**
- **control statements (*)**
- **internal commands (*)**
- **special server commands (*)**
- **pre-processor commands (*)**

Calling scripts (procedure/function call): (*)

Scripts can be added as new operators to GUI (*)

8/28/2008

VisionLab

47



Demonstration script image operators



- **Create new script, add the lines by selecting the operators from the menus (not necessary to type them):**
 - `lread i circles.jl`
 - `display i`
- **Execute script**
- **Insert with mouse threshold command, and adapt 'imageName', explain why**
- **Execute script**
- **Demonstrate convolution instead of threshold:**
 - `convolution i ii gausian3x3`
 - `display ii`
- **Change to SobelINS by doubleclick on convolution line in script**

8/28/2008

VisionLab

48





Demonstration script variables and control statements


- This script calculates the average area of the selected blobs
- Open scripts **ba_example.jls**
- Open variable screen (Server menu | Examine variables)
- Single step through script
- Notes:
 - result is returned to an array with name tab
 - Click on array name in top window of variable screen to examine details of array
 - each element of the array contains a line with: <labelnr> followed with the specified measurements
 - Each line is extracted from the array tab to an array elm
 - The element with index 0 of array elm is the labelnr
 - The element with index 1 of array elm is the area
 - The element with index 2 of array elm is the formfactor

8/28/2008

VisionLab

53

Demonstration script variables and control statements



```

VisionLab V3.37 8-11-2007 (c) Van de Loosdrecht Machine Vision www.vdlmv.nl
File Operator Camera Server Options Window User1 User2 User3 User4 User5 User6 Help
C:\VisionCursus\Vision2007c\images\ba_example.jls
Internal script Search Line number Indentation
name [ ] Store Find Jump + - c
lread i cells.jls
ThresholdIsodata i BrightObject
$nrBlobs = LabelBlobs i EightConnected
$maxBlob = BlobAnalysisArray i &$tab SortUp Area UseY Area FormFactor
$total = 0
for $i = 0 to $maxBlob do
  VarToArray &$tab[$i] &$elm
  $label = $elm[0]
  $area = $elm[1]
  $ff = $elm[2]
  $total = $total + $area
endfor
$avgArea = $total / $nrBlobs



```



Execute F9 | Abort Ctrl+Y | Protected | Continue | Single step | Step into | Reset | stay on top | Update | Remove | RemoveAll | Close | 0 us | < >

8/28/2008

VisionLab

54





Script variables (*)

Variables are of type string. When necessary a conversion is applied to type integer, float or boolean.

There are two type of variables:

- **global:** Scope is all scripts and outside the scripts. Lifetime is from creation to the moment it is removed explicitly by the user. The name of a global variable starts with one \$ sign, example: \$global
- **local:** scope and lifetime is the script in which the variable is created. The name of a local variable starts with two \$ signs, example: \$\$local

The value of the variables can be examined and modified with the 'Examine vars' item in the server menu.

8/28/2008

VisionLab

59



Demonstration script variables (*)

- open script script_vars.jls
- execute script
- open window 'Examine vars' in the server menu
- explain: Main menu | Options | Synchronize scripts

8/28/2008

VisionLab

60



Array's of variables (*)

Operators for manipulation of array's:

- **ArrayToVar &\$array &\$var**, convert array to var
- **CopyVar &\$src &\$dest**, copy array from src to dest
- **GetDimVar &\$array**, result is dimension of array
- **SetDimVar &\$array dimension**
- **VarToArray &\$var &\$array**, convert var to array, each word in var is new element in array
- **ArrayToFile <fileName> &\$array**
- **ArrayFromFile <fileName> &\$array**
- **LArrayToFile <fileName> &\$array**
- **LArrayFromFile <fileName> &\$array**

8/28/2008

VisionLab

63

Script expressions (*)

Simple forms of expressions are possible:

- **<var> = <var>**
- **<var> = <constant>**
- **<var> = <var> <operator> <var>**
- **<var> = <var> <operator> <constant>**

Note there is not yet support for brackets () in expressions.

The following operators are supported: + - * / mod and or ! == != <
 <= > >= .

8/28/2008

VisionLab

64

Script expressions (*)

**Arithmetic and Boolean expressions are possible,
use brackets () for priorities in Boolean expressions.**

Note: all operators and must be separated by spaces.

Examples:

`$r = ($x + $v) * 4`
`$b = ! ($b1 and (bt[$i] or $b2))`

It is not possible to call a function in expressions.

Prohibit evaluation by using "", example:

`$cg = "(10,15)"`

8/28/2008

VisionLab

65


Demonstration script expressions (*)

- open script `script_expres.jls`
- execute script
- open window 'Examine vars' in the server menu
- click continue script
- click continue script
- explain `break(points)`, `reset` and `single stepping` scripts

8/28/2008

VisionLab


66



8/28/2008

VisionLab



67




8/28/2008

VisionLab

68



Parameter by value (*)

```
script0
Internal script
name [ ] Store
$var = "een twee drie"
$res = getfirstword $var
break

$res = removefirstword &$var
```

Variables

```
res = een
var = een twee drie
```

Name [] Value []

stay on top Update Remove RemoveAll Close


Execute Continue Single step Step into Reset

0 us res = een var = een twee drie

8/28/2008

VisionLab

71

Parameter by reference (*)

```
script0
Internal script
name [ ] Store
$var = "een twee drie"
$res = getfirstword $var
break

$res = removefirstword &$var
```

Variables

```
res = een
var = twee drie
```

Name [] Value []

stay on top Update Remove RemoveAll Close

Execute Continue Single step Step into Reset

0 us res = een var = twee drie

8/28/2008

VisionLab

72

Operators for string manipulation (*)

A variable can be initialized with a string using double quotes.

Example: `$s = "here are spaces allowed"`

. is dyadic operator used for string concatenation.

Note this operator is used for concatenation of chars in a word.

If used as `$v . $w`, both `$v` and `$w` must be non empty variables with one word as value.

Use for concatenation of words the string operator `Concat`.

8/28/2008

VisionLab

73

Operators for string manipulation (*)

A variable can be initialised with a string using double quotes.

Example: `$s = "here are spaces allowed"`

- `getfirstword <var>`
- `getfirstnwords <n> <var>`
- `getnthword <n> <var>`
- `getnthfromvector <n> <var>`
- `vector <i1> <i2> <i3>`
- `listallvars`
- `removefirstword <&var>`
- `removefirstnwords <n> <&var>`
- `removeuntilword <word> <&var>`
- `strip <&var>`

8/28/2008

VisionLab

74

Operators for special string manipulation (*)

- `getvar <&var>`
- `isequalvar <&var1> <&var2>`
- `removevar <&var>`
- `removeallvars`
- `setvar <&var> <value>`
- `isvar <varname without $>`
- `testequalvar <&var1> <&var2>`
- `concat <sequence of <var> and text>`
- `substr <&var> <offset> <count>`
- `length <&var>`
- `find <&str> <key> <offset>`, find substring in string
- `findfirstof <&str> <key> <offset>`, find character in string
- `findlastof <&str> <key> <offset>`, find character in string

For more details of operators, see online help

8/28/2008

VisionLab

75

Math operators for vars (*)

- `asin <x>`
- `acos <x>`
- `atan <x>`
- `atan2 <y> <x>`
- `ceil <x>`
- `cos <x>`
- `cosh <x>`
- `exp <x>`
- `fabs <x>`
- `floattoint <x>`
- `floor <x>`
- `fmod <x> <y>`
- `initrandomgen <x>`
- `log <x>`
- `log10 <x>`
- `mod <x> <y>`
- `pow <x> <y>`
- `random <low> <high>`
- `randomint <low><high>`
- `sin <x>`
- `sinh <x>`
- `sqrt <x>`
- `tan <x>`
- `tanh <x>`

8/28/2008

VisionLab

76

Script control statements (*)

Nesting to arbitrary depth is possible

```
if <condition> then
    <statement block>
else
    <statement block>
endif

while <condition> do
    <statement block>
endwhile

for<var> = <expression> (<to>|<downto>) <expression> do
    <statement block>
endfor
```

8/28/2008

VisionLab

77

Script control statements (*)

```
switch <expression>
case <tag>
    <statement block>
case <tag>
    <statement block>
default
    <statement block>
endswitch

return <expression> // function return

label <labelName>
goto <labelName>
```

8/28/2008

VisionLab

78

Demonstration script control statements (*)


- open script script_stat.jls
- execute script
- open window 'Examine vars' in the server menu
- click continue script
- click continue script

8/28/2008

VisionLab

79

Demonstration script control statements (*)



The screenshot shows the VisionLab V3.29 interface. The main window displays an internal script named 'script_stat.jls' with the following code:

```
$v1 = 3
if $v1 >= 2 then
  if $v1 < 4 then
    $v3 = "then1"
  else
    $v3 = "else1"
  endif
else
  if $v1 == 1 then
    $v3 = "then2"
  else
    $v3 = "else2"
  endif
endif
break
```

To the right of the script, a 'Variables' window is open, showing the current variable values:



Variable	Value
v1	3
v3	then1

At the bottom of the interface, a 'Server log' window shows the output: '0 us then1'.

8/28/2008

VisionLab

80



Internal commands (*)

Internal commands are special local commands for which there is not a (direct) server command.

Examples :

- **lcwd <path>:** change working directory of client to path
- **lpwd:** return working directory of client.
- **lread <imagename> <filename>:** The file with <filename> is read on the client and added to the server as image with <imagename>
- **lwrite <imagename> <filename>:** The image with <imagename> is written on the client as file with <filename>
- **display <name>:** The image with <name> is displayed
- **GUIForm:** create dialog box from script
- **see also on-line help for more examples**

8/28/2008

VisionLab

83

Demonstration GUIForm: create dialog box from script (*)

GUIForm <caption> {<spinedit> | <editbox>}

Displays a dynamic form from a script in order to query the user with inputs, result is a string with the answers.

- spinedit: <prompt> <default> <low> <high>

A spinedit field is added to the form with a prompt and a default value. Low and high specify the extreme possible values.



- editbox: <prompt> <default>



An editfield is added to the form with a prompt and a default value.

8/28/2008

VisionLab

84





Date and time commands (*)

- **Time**: returns <day> <month> <dayInMonth> <hh:mm:ss> <year>
- **Delay <secs>**: delay operations for secs seconds time.
- **MicroDelay <us>**: delay operations for us micro-seconds time.
- **MilliDelay <ms>**: delay operations for ms milli-seconds time.
- **ResetTimeStamp**: reset time stamp counter to zero
- **MicroTimeStamp**: return a time stamp in micro seconds, note: maximum time for overflow after reset is 35 minutes.
- **MilliTimeStamp**: return a time stamp in mille seconds, note: maximum time for overflow after reset is 583 hours.

8/28/2008

VisionLab

89

Pre-processor commands (*)

A command is pre-processed before it is executed. The following pre-processor commands are only available in the client:

- **%currentimage**: this command is replaced with the name of the current selected image or the name of the image selected as script image
- **%secondimage**: this command is replaced with the name of the image selected as second image
- **%thirdimage**: this command is replaced with the name of the image selected as third image
- **%startupdir**: directory name from which the client has been launched

8/28/2008

VisionLab

90

Script procedure calls (*)

There are three different kind of scripts:

- local scripts: script is executed in the client or called with the *lcall* command from a script executed in the client
- remote file scripts: script is executed in the server. Script is started with a *call* <remote fileName> <params> command
- internal script: script is executed in the server. Before being started with a *lcall* <internal scriptName> <params> command the script has to be stored in the server

The formal parameters have the form %pn, where n starts at 1
The first parameter is %p1, the next %p2 etc

A script can return a function result with the return command
return <function result>

Local scripts can be aborted with <control y>

8/28/2008

VisionLab

91



Demonstration script procedure calls (*)


- open script script_call.jls
- click single step
- click single step
- click step into
- click single step
- click single step
- open window 'Examine vars' in the server menu
- click continue script

8/28/2008

VisionLab

92






8/28/2008

VisionLab

95



8/28/2008

VisionLab

96

Demonstration speed up by using internal script (*)


- open script internal_example.jls
- run script to first break point
- examine variables
- examine script intern_script.jls
- run (continue) second part of script and compare executing times
- \$time_local = 6411 ms
- \$time_intern = 176 ms
- Note: this example is just to demonstrate internal scripts. A much faster way to calculate the average area is to count the number of object pixels and divide this number with the number of object

8/28/2008

VisionLab

97

open script internal_example.jls (*)



```

VisionLab V3.37 8-11-2007 (c) Van de Loosdrecht Machine Vision www.vdlmv.nl
File Operator Camera Server Options Window User1 User2 User3 User4 User5 User6 Help

C:\VisionCursus\Vision2007c\images\intern_example.jls
Internal script Search Line number Indentation
name | Store Find 28 Jump + - c

lread i cells.jl
ThresholdIsodata i BrightObject
$nrBlobs = LabelBlobs i EightConnected

ResetTimeStamp

$maxBlob = BlobAnalysisArray i &$tab SortUp Area UseY Area FormFactor
$total = 0
for $i = 0 to $maxBlob do
  VarToArray &$tab[$i] &$elm
  $label = $elm[0]
  $area = $elm[1]
  $ff = $elm[2]
  $total = $total + $area
endfor
$avgArea = $total / $nrBlobs

$time_local = MilliTimeStamp
break



Execute F9 Abort Ctrl+Y Protected Continue Single step Step into Reset
0 us can not save this type of form

```


8/28/2008

VisionLab

98



run second part of script and compare executing times(*)



The screenshot shows the VisionLab V3.37 software interface. The main window title is "VisionLab V3.37 8-11-2007 (c) Van de Loosdrecht Machine Vision www.vdlmv.nl". The menu bar includes File, Operator, Camera, Server, Options, Window, User1, User2, User3, User4, User5, User6, and Help. The script editor window contains the following JScript code:

```

Internal script
Search
name | Store | Find

$nrBlobs = LabelBlobs i EightConnected

ResetTimeStamp

$maxBlob = BlobAnalysisArray i &$tab SortUp Area U
$total = 0
for $i = 0 to $maxBlob do
  VarToArray &$tab[$i] &$elm
  $label = $elm[0]
  $area = $elm[1]
  $ff = $elm[2]
  $total = $total + $area
endfor
$avgArea = $total / $nrBlobs

$time_local = MilliTimeStamp
break

1AddScript intern intern_script.jls
iCall intern

```

The Variables window on the right lists several variables with their values:

- area = 1
- avgArea = 58.25
- elm = array(3) <71..1>
- ff = 1
- i = 99
- label = 71
- maxBlob = 99
- nrBlobs = 100
- tab = array(100) <18 898 1.02991..71 11>
- time_intern = 176
- time_local = 6411
- total = 5825

At the bottom of the interface, there are buttons for Execute F9, Abort Ctrl+C, Protected, Continue, Single step, Step into, and Reset. There are also checkboxes for "stay on top", "Update", "Remove", and "RemoveAll". The status bar at the bottom shows the date "8/28/2008", the application name "VisionLab", and the page number "101".

Speeding up scripts (*)

- **System settings**
 - **Disable client logging:**
set in main menu item server log to “no log”
 - **Disable server logging and Disable history mechanism:**
close visionlab
open file visionlab.ini
search in file for “[localserver]”
next line has item “exename” with syntax
vissvr.exe <port> <byteorder> <timeout> <maxhissize> <EchoOn|EchoOff> <(no)debug>
set <maxhissize> to 0
set <EchoOn|EchoOff> to EchoOff
example: “exename=vissvr.exe 2066 NativeByteOrder 5 0 EchoOff nodebug”
save and close file visionlab.ini
start VisionLab again

8/28/2008

VisionLab

102

Adding a script as new operator (*)

New operators can be added to the system by editing the file visionlab.ini.
See for more details [Adding a new operator to the client](#)

Example:

An operator with the name Script must be added to the usermenu. When the operator is selected the script with name test.jls is to be executed and it will receive three parameters.

In order to make this possible add the following lines to the file visionlab.ini and startup the system.

```
[examplescript]
menu=UserMenu
caption=Example &Script
class=IntImage
script=test.jls
paramform=scriptparam
selectedimage source
editbox low 0
editbox high 80
```

8/28/2008

VisionLab

103

Adding a script as new operator (*)

Explanation:

[examplescript]: In [] the name of the operator. Note: no white space behind] is allowed.

menu: The menu where the operator is added to the system.

caption: The name used for the operator in the menu. The & give the letter for the shortkey.

class: The highest class in the Image hierarchy overview on which the operator can work.

script: The filename of the script which is to be executed.

paramform: Specifies the form which to be used to ask the user for the parameters. Currently for user scripts only 'scriptparam' is supported.

8/28/2008

VisionLab

104

Adding a script as new operator (*)

The section following paramform specifies the parameters for the operator. The maximal number of parameters is 25. The parameters are displayed and send to the server in the same order as they are declared. There are the following possibilities:

- selectedimage <prompt>: An edit field is added with a prompt and the image name of the currently selected image
- 2ndselected <prompt>: An edit field is added with a prompt and the image name of the 2ndselected image
- 3rdselected <prompt>: An edit field is added with a prompt and the image name of the 3rdselected image.
- genimagename <prompt>: An edit field is added with a prompt and a generated image name
- spinedit <prompt> <default> <low> <high>: A spinedit field is added with a prompt and a default value. Low and high specify the extreme possible values

8/28/2008

VisionLab

105

Adding a script as new operator (*)

- editbox <prompt> <default>: An edit field is added with a prompt and a default value
- combobox <prompt> <default> <item1> ... <itemN>: A combo box is added with a prompt and a default value. The combobox is filled with the specified items. If prompt equals to 'none' combobox is invisible

8/28/2008

VisionLab

106


Example: Adding an own script as operator (*)

- Demonstrate own_script.jls in User Menu item 'example script' on circles.jl and look at vislab.ini for added script as new operator.

8/28/2008

VisionLab

107

Example: Adding an own script as operator (*)

8/28/2008

VisionLab

108

VisionLab.ini configuration file (*)

```

Visionlab.ini - Notepad
File Edit Format Help
[File]
// File      : visionLab.ini
// Version   : 3.29
// Project   : VisionLab, configuration file
// Author    : Jaap van de Loosdrecht, jaap@vdlmv.nl
// Date      : 11-12-2002
// Copyright (c) 1993-2002 Van de Loosdrecht Machine vision, all rights reserved.

[options]
imagegeneration=new new inplace
reducefactor=1 1 20
printscale=10 1 1000
timer=single accumulate single
infile=save save do_not_save
syncscripts=not_synchronise synchronise not_synchronise
stayontop=not_on_top not_on_top on_top
precision=6 1 40
byte8lut=stretch stretch Clip Binary Labelled
int8lut=stretch stretch Clip Binary Labelled
int16lut=stretch stretch Clip Binary Labelled
int32lut=stretch stretch Clip Binary Labelled
floatlut=FloatLog FloatLog FloatLinear
doublelut=FloatLog FloatLog FloatLinear
complexlut=FloatLog FloatLog FloatLinear
rgb888lut=default default
hsv888lut=default default

[serveroptions]
hostname=localhost
portnumber=2066
byteorder=native
logmode=LogNormal
timeout=600

```

8/28/2008

VisionLab

109

Adding script own_script.jls as operator in visionlab.ini (*)

```

Visionlab.ini - Notepad
File Edit Format Help
[usersetall]
menu=UserMenu
caption=&User Set All
class=intImage
help=0
shortcut=none
command=usersetall
source=copy
result=image
paramform=varparam
selectedimage image
spinedit pixel 1 -32000 32000

[examplescript]
menu=UserMenu
caption=&Example Script
class=intImage
help=0
shortcut=none
script=own_script.jls
paramform=scriptparam
selectedimage image
editbox low 0
editbox high 80

[Curvature]
menu=UserMenu
caption=&Curvature
class=intImage
help=0
shortcut=none

```

8/28/2008

VisionLab

110

Adding an own C++ operator (*)

Add new operator to server to set all pixels to same value

- Write new operator in C++ (UserSetAll)
- Write envelope for operator (SetAllCmd)
- Add envelope to cmd interpreter (Main in visserv.cpp)
- Command send to server will be: usersetall <image name> <pixel value>
- The server will use the first word as name of the command ("usersetall") and will use this name to find the associated envelope function SetAllCmd
- SetAllCmd will get as input stream the command without the first word: "<image name> <pixel value>"
- SetAllCmd will:
 - read the image name and pixel value from the inputs stream
 - check whether image name is a valid image
 - call UserSetAll with image and value as parameter
 - the call to userSetAll is surrounded with timer functions which supports the displaying of the time needed for the operation in the left bottom corner of the GUI
 - The call AddLastCmdToHistory adds the command to the history list of the image

Add new operator to GUI

- Edit vislab.ini


See for example the files in the src directory of the SDK:
useroper.h, useroper.cpp and visserv.cpp

8/28/2008

VisionLab

111

useroper.h (*)



```

useroper.h - Notepad
File Edit Format View Help
/* File : useroper.h
 * Project : visionlib v3.0
 * Author : Jaap van de Loosdrecht
 *           Van de Loosdrecht Machine Vision
 *           www.vdlmv.nl
 * Date : 1-1-2003
 *
 * Copyright (c) 1993-2003, van de Loosdrecht Machine Vision,
 * all rights reserved.
 */
#ifndef JL_VIS_LIB_USER_OPERATOR
#define JL_VIS_LIB_USER_OPERATOR
#include "Int16Image.h"
#include "VisLibCmd.h"
void UserSetAll(Int16Image &image, const Int16Pixel pixel);
void InsertUserOperCmds(VisLibCmdInt &cmdInt);
#endif

```

8/28/2008

VisionLab

112

useroper.cpp (*)

```

useroper.cpp - Notepad
File Edit Format View Help
using namespace JL_VisionLib_v3;

// the new operator itself
void UserSetAll (Int16Image &image, const Int16Pixel pixel) {
    for (int16 y = 0; y < image.GetHeight(); y++) {
        for (int x = 0; x < image.GetWidth(); x++) {
            image(x,y) = pixel;
        }
    }
}

/* alternative faster solution using pointers:
Int16Pixel *ownPtr = image.GetFirstPixelPtr();
Int16Pixel *lastPtr = image.GetLastPixelPtr();
while (ownPtr <= lastPtr) {
    *ownPtr++ = pixel;
} // for all pixels */
} // UserSetAll

// the following code envelope is necessary to add the new operator to the server
static void SetAllCmd (istream &is, ostream &os, VisLibCmdInt &cmdInt) {
    OString imageName;
    Int16Pixel pixel;
    is >> imageName >> pixel;
    if (is.fail()) throw (error ("[SetAll] input error"));
    if (CheckIsInt16Image (cmdInt, imageName, os)) {
        Int16Image *src = dynamic_cast <Int16Image * > (cmdInt.GetImage (imageName));
        cmdInt.StartTimer();
        UserSetAll (*src, pixel);
        cmdInt.StopTimer();
        cmdInt.AddLastCmdToHistory (imageName);
        os << "example of a result string";
    }
} // SetAllCmd

// called by the main program
void InsertUserOperCmds (VisLibCmdInt &cmdInt) {
    cmdInt.InsertCmd ("UserSetAll", CmdIntCommand (SetAllCmd, cmdInt), "<imageName> <pixelvalue>");
} // InsertUserOperCmds

```

8/28/2008 VisionLab 113

visserv.cpp (*)



```

visserv.cpp - Notepad
File Edit Format View Help
.....
int main (int argc, char *argv[])
{
    VisLibCmdInt cmdInt(debug);
    VisLibSrv server(cmdInt, port, byteOrder, timeOut);

    // register camera's
    // RegisterFireCam (cmdInt);
    RegisterDummyCam (cmdInt);
    RegisterFileCam (cmdInt);
    // RegisterRioCam (cmdInt);
    // examples:
    InsertUserOperCmds (cmdInt); // simple user defined operator
    // Insert your own cmds <----->
    server.Run();
}
} // main

```

8/28/2008 VisionLab 114



Adding a new C++ operator to the client (*)

[usersetall]: In [] the name of the operator. Note: no white space behind] is allowed.

menu: The menu where the operator is added to the system.

caption: The name used for the operator in the menu. The & give the letter for the shortkey.

class: The highest class in the Image hierarchy overview on which the operator can work, or "Nolimage" if operator does not work with images.

shortcut: The name for a key on the keyboard, which can activate the operator without using the menu. Possible values: none, ctrl+a, .. ctrl+z, f1, .. f12, ctrl+f1, .. ctrl+f12, shift+f1, .. shift+f12, shift+ctrl+f1, .. shift+ctrl+f12, ins, shift+ins, ctrl+ins, del, shift+del, ctrl+del, alt+bksp and shift+alt+bksp.

command: The command name which is sent to the server.

8/28/2008

VisionLab

117

Adding a new C++ operator to the client (*)

source: Specifies on which image operation is performed, possible values:

- original: operation is performed on the source image.
- copy: operation is performed on a copy of the original, the name of the copy is either specified by a imagename parameter (see below: description of paramform) or generated by the system.
- none: operation is not performed on an image.

result: Determines how the result of the operation is to be displayed, possible values:

- image: The image (= first parameter) on which the operation was performed is displayed.
- 2ndimage: The image specified as second parameter in the parameter list of the server command is displayed.
- 3rdimage: The image specified as third parameter in the parameter list of the server command is displayed.
- 4thimage: The image specified as fourthparameter in the parameter list of the server command is displayed.
- 2nd3rdimage: The images specified as second and third parameter in the parameter list of the server command are displayed.

8/28/2008

VisionLab

118

Adding a new C++ operator to the client (*)

result (continued):

- 2nd3rd4thimage: The images specified as second, third and fourth parameter in the parameter list of the server command are displayed.
- bothimages: image and 2ndimage are displayed, see above.
- box: As result a string with the format '(x1,y1) (x2,y2)' is expected from the server. A box with lefttop (x1,y1) and rightbottom (x2,y2) is drawn in the current active image.
- circle: As result a string with the format '(x,y) r h' is expected from the server. A circle with centre (x,y) and radius r is drawn in the current active image. h is the number of hits.
- circles: As result a string with the format 'n (x,y) r h ... (x,y) r h' is expected from the server. N circles with centres (x,y) and radius r are drawn in the current active image.
- line: As result a string with the format '(x1,y1) (x2,y2)' is expected from the server. A line from (x1,y1) to (x2,y2) is drawn in the current active image.
- polarline: As result a string with the format '(r,phi) h' is expected from the server. A line with polarcoordinates is drawn in the current active image. h is the number of hits.

8/28/2008

VisionLab

119

Adding a new C++ operator to the client (*)

result (continued):

- polarlines: As result a string with the format 'n (r,phi) h ... (r,phi) h' is expected from the server. N lines with polarcoordinates is drawn in the current active image. h is the number of hits.
- string: As result a string is expected from the server which is displayed in the info bar.
- stringlist: As result a list of strings is expected from the server which is displayed in a window.
- nothing: Nothing is displayed.

paramform: Specifies the form which to be used to ask the user for the parameters. Currently for user C++ operators only varparam is supported.

The section following paramform specifies the parameters for the operator. The maximal number of parameters is 25. The parameters are displayed and sent to the server in the same order as they are declared.

8/28/2008

VisionLab

120

Adding a new C++ operator to the client (*)

There are the following possibilities for the parameters :

- **selectedimage <prompt>:** An editfield is added with a prompt and the image name of the currently selected image.
- **2ndselected <prompt>:** An editfield is added with a prompt and the image name of the 2ndselected image.
- **3rdselected <prompt>:** An editfield is added with a prompt and the image name of the 3rdselected image.
- **genimagename <prompt>:** An editfield is added with a prompt and a generated image name.
- **spinedit <prompt> <default> <low> <high>:** A spinedit field is added with a prompt and a default value. Low and high specify the extreme possible values.
- **editbox <prompt> <default>:** An editfield is added with a prompt and a default value.
- **combobox <prompt> <default> <item1> ... <itemN>:** A combo box is added with a prompt and a default value. The combobox is filled with the specified items.

8/28/2008

VisionLab

121

Adding a new C++ operator to the client (*)

Possibilities for the parameters (continued):

- **checkboxlist <prompt> <defaults> <|> <item1> ... <itemN>:** A checkboxlist is added with a prompt and default check values. The listbox is filled with the specified items.
NOTE: this parameter can ONLY be used as the last parameter of a command.

8/28/2008

VisionLab

122