

```
1  #include "Microscope.h"
2
3  //Custom exceptions
4  #include "MicroscopeNotFoundException.h"
5  #include "CouldNotGrabImageException.h"
6
7  using namespace cv;
8
9  namespace Hardware
10 {
11     Microscope::Microscope()
12     {
13         FrameDelayTrigger = 3;
14         Dimensions = Resolution{ 2592, 1944 };
15
16         try { openCam(); }
17         catch (Exception::MicroscopeNotFoundException& e)
18         {
19             // Tries to soft reset the USB port. Haven't got this working yet
20             USB usbdev;
21             usbdev.ResetUSB();
22             captureDevice.open(0);
23             if (!captureDevice.isOpened())
24             {
25                 throw Exception::MicroscopeNotFoundException("Soft reset of microscope didn't work. Try turning the soil analyzer on
26                                     and off again!");
27             }
28         }
29     }
30
31     /*! Constructor of the class which initializes the USB microscope
32     \param frameDelayTrigger the delay between the first initialization of the microscope and the retrieval of the image expressed in
33         seconds. Default value is 3 seconds
34     \param dimension A resolution Struct indicating which resolution the webcam should use. Default is 2592 x 1944
35     */
36     Microscope::Microscope(uint8_t frameDelayTrigger, Resolution dimensions)
37     {
38         FrameDelayTrigger = frameDelayTrigger;
39         Dimensions = dimensions;
40
41         try { openCam(); }
42         catch (Exception::MicroscopeNotFoundException& e)
```

```
41     {
42         // Tries to soft reset the USB port. Haven't got this working yet
43         USB usbdev;
44         usbdev.ResetUSB();
45         captureDevice.open(0);
46         if (!captureDevice.isOpened())
47         {
48             throw Exception::MicroscopeNotFoundException("Soft reset of microscope didn't work. Try turning the soil analyzer on
49             and off again!");
50         }
51     }
52
53     /*!< De-constructor*/
54     Microscope::~Microscope()
55     {
56         captureDevice.~VideoCapture();
57     }
58
59     /*! Get the frame after the set initialization period
60     \param dst a cv::Mat construct which stores the retrieved image
61     */
62     void Microscope::GetFrame(cv::Mat &dst)
63     {
64         if (!captureDevice.grab()) { throw Exception::CouldNotGrabImageException(); }
65         sleep(FrameDelayTrigger); // Needed otherwise scrambled picture
66         if (!captureDevice.grab()) { throw Exception::CouldNotGrabImageException(); }
67         captureDevice.retrieve(dst);
68     }
69
70     /*! Get an HDR capture of the cam using a user defined number of frames differently lit frames. Due to hardware limitations each
71     frames take roughly 3 seconds to grab. This function is based upon the tutorial from openCV http://docs.opencv.org/trunk/doc/
72     tutorials/photo/hdr\_imaging/hdr\_imaging.html
73     \param dst a cv::Mat construct with the retrieved HDR result
74     \param noframes is the number of frames that create the HDR image - default = 5
75     */
76     void Microscope::GetHDRFrame(cv::Mat &dst, uint32_t noframes)
77     {
78         //create the brightness steps
79         int8_t brightnessStep = static_cast<int8_t>((MAX_BRIGHTNESS - MIN_BRIGHTNESS)/ noframes);
80         int8_t currentBrightness = captureDevice.get(CV_CAP_PROP_BRIGHTNESS);
81         int8_t currentContrast = captureDevice.get(CV_CAP_PROP_CONTRAST);
```

```
80     captureDevice.set(CV_CAP_PROP_CONTRAST, MAX_CONTRAST);
81
82     Mat currentImg;
83
84     // take the shots at different brightness levels
85     for (uint32_t i = 1; i <= noframes; i++)
86     {
87         captureDevice.set(CV_CAP_PROP_BRIGHTNESS, (MIN_BRIGHTNESS + (i * brightnessStep)));
88         GetFrame(currentImg);
89         HDRframes.push_back(currentImg);
90     }
91
92     // Set the brightness and back to the previous used level
93     captureDevice.set(CV_CAP_PROP_BRIGHTNESS, currentBrightness);
94     captureDevice.set(CV_CAP_PROP_CONTRAST, currentContrast);
95
96     // Perform the exposure fusion
97     Mat fusion;
98     Ptr<MergeMertens> merge_mertens = createMergeMertens();
99     merge_mertens->process(HDRframes, fusion);
100     fusion *= 255;
101     fusion.convertTo(dst, CV_8UC1);
102 }
103
104 /*!< Checks if the capture device is open and returns the status as a bool
105 /return Status of the capture device expressed as a bool
106 */
107 bool Microscope::IsOpened()
108 {
109     return captureDevice.isOpened();
110 }
111
112 /*!< Safely release the capture device*/
113 void Microscope::Release()
114 {
115     captureDevice.release();
116 }
117
118 /*!< Opens the webcam*/
119 void Microscope::openCam()
120 {
121     captureDevice.open(0);
```

```
122  
123     if (!captureDevice.isOpened()) { throw Exception::MicroscopeNotFoundException(); }  
124     captureDevice.set(CV_CAP_PROP_FRAME_WIDTH, Dimensions.Width);  
125     captureDevice.set(CV_CAP_PROP_FRAME_HEIGHT, Dimensions.Height);  
126 }  
127 }
```